

TOYOTA LAND CRUISER



1996 Factory Service Manual

INDEX

AC	Air Conditioning
AT	Automatic Transmission
BE	Body Electrical
BO	Body
BR	Brakes
CH	Charging System
CO	Cooling
DI	Diagnostics
EC	Emission Control
EM	Engine Mechanical
IG	Ignition

LU	Lubrication
MA	Maintenance
PP	Preparation
PR	Propeller (Drive) Shaft
RS	Supplemental Restraint Sys.
SA	Suspension & Axle
SF	Sequential Fuel Injection (SFI)
SR	Steering
SS	Service Specs
ST	Starting
TR	Transfer Assembly (Case)