FUEL SUCTION PLATE WITH FILTER ASSEMBLY

NO. 1 FUEL SUCTION SUPPORT

FUEL PUMP HARNESS

FUEL MAIN VALVE ASSEMBLY

● O-RING

● O-RING

SPACER

FUEL PUMP

FUEL SENDER GAUGE ASSEMBLY

NO. 1 FUEL SUB-TANK

● Non-reusable part

P