RADIO AND PLAYER

* 1 : SHIELDED

FROM POWER SOURCE SYSTEM (SEE PAGE 54)

F11 FUSE BLOCK: 10A GAUGE, 15A CIG

20A RADIO

J4 JUNCTION CONNECTOR

J3 JUNCTION CONNECTOR

C17 COOLING FAN (RADIO AND PLAYER)

A30 AUTO ANTENNA ECU: ACC, ANT

I15, I20

FROM " TAIL" FUSE

C19 CD AUTOMATIC CHANGER: +B, ACC, ILL+, GND, IP−, IP+, CDL−, CDR−, CDL+, CDR+, SGND

R1 (A), R2 (B) RADIO AND PLAYER: ANT, AMP, ACC, +B, MUTE, FL, FR, GND, BEEP, RL, RR, GND, TELL MUTE

S15 (A), S16 (B), S17 (C) STEREO COMPONENT AMPLIFIER: ACC, +B, AMP+, RACC, +B, MUTE, FL, FR, SGND, BEEP, RL, RR, GND

E, FL+, FL−, FR+, FR−, WF+, WF−, RR+, RR−, RL+, RL−

F9 FRONT TWEETER SPEAKER LH

F10 FRONT TWEETER SPEAKER RH

F14 FRONT DOOR SPEAKER LH

F15 FRONT DOOR SPEAKER RH

W6 WOOFER SPEAKER

R12 REAR DOOR SPEAKER RH

R11 REAR DOOR SPEAKER LH

T8 (A), T9 (B) TELEPHONE TRANSCEIVER AND SPEAKER RELAY: AUD+, AUD−, MUTE, SP+, SP−

J7 JUNCTION CONNECTOR

ID, IE