Rewiring Driver's Side Window Master Switch Connector (if Pass side window does not respond properly)

<u>See the diagram below.</u>

In the OEM connector, the top left slot is empty (when held with the 'clicking slot' on the top) and the upper slot on the right hand flange is occupied by a blue/white wire- see circles. In the Switch Doctor connector, the blue/white wire incorrectly goes to the top left slot.

To correct: In the Switch Doctor connector, remove the blue/white wire and spade by pulling away the snap thingy on the inside of the connector that holds the spade in and pull the wire and spade out the back end of the connector. Then insert the blue/white wire and spade in the upper slot on the right hand flange. Then all should be well.

OEM **Switch Doctor**

