
How far should this rod be "up" into the Steering column when static?
It seems to me that on a collapsible column it should be out a ways towards the steering box?