

Factors to adjust for altitude when performing compression tests:

<u>Altitude</u>	<u>Factor</u>
1,000	0.9711
2,000	0.9428
3,000	0.9151
4,000	0.8881
5,000	0.8617
6,000	0.8359
7,000	0.8106
7,240	0.8047
8,000	0.7860

Divide compression reading by above factors to obtain corrected values.