NOTICE

FRAME NUMBER AND VEHICLE IDENTIFICATION NUMBER

1. FRAME NUMBER FJ60-123456

FRAME NUMBER IS GIVEN ON THE DASH COWL IN THE ENGINE ROOM FUNCTION IF TOYOTA PARTS CATALOG IS LISTED IN THE REVISION REFERENCE CODE LIST TO IDENTIFY ENGINEERING CHANGE PERIOD AS BEFORE. SO IN LOOKING PARTS CATALOG, TAKE A LOOK AT FRAME NUMBER ON CORRESPONDING VEHICLE.

REV. REF. CODE	ENGINE NO. OR FRAME NO.
1	FJ60-123456

2. NAME PLATE

NAME PLATE IS ATTACHED TO THE DASH COWL IN THE ENGINE ROOM. MODEL COLUMN INDICATES FULL MODEL CODE, SO, FOR MODEL INFORMATION, REFER TO THE NAME PLATE AS BEFORE.

PROCEDURE TO DETERMINE FRAME NUMBER FROM NAME PLATE IS ;

ⓐ + ⓑ =

FJ60-123456

ENGINE 2F 4230cc. 258.1 cu.in.

TOYOTA MOTOR CORPORATION

JT3FJ60GXB1123456 (ⓑ)

MODEL FJ60LG-KA (ⓐ)

C/TR/PTR

3. VEHICLE IDENTIFICATION NUMBER JT3FJ60GXB1 123456

VEHICLE IDENTIFICATION NUMBER IS GIVEN TO V N PLATE ON LEFT HAND OF DASH BOARD, CERTIFICATION REGULATION PLATE ON LEFT DOOR PILLAR, AND NAME PLATE.

NOTICE

FRAME NUMBERING IS STARTED FROM DIFFERENT STARTING FRAME NUMBER PER EACH ASSEMBLY LINE.

WHEN REFERRING TO STARTING FRAME NUMBER ON REVISION REFERENCE CODE LIST, BEAR FOLLOWING MATTER IN YOUR MIND.

Starting Frame Number Per Each Assembly Line

Assembly Line / Applicable Model	Toyota Motor Honsya Plant (A11)
BJ60–	000001 ~
FJ60–	000001 ~
HJ60–	000001 ~

REV. REF. CODE	ENGINE NO. OR FRAME NO.	REV. REF. CODE	ENGINE NO. OR FRAME NO.	REV. REF. CODE	ENGINE NO. OR FRAME NO.
455	FJ60-000001	482	BJ60-0011092	537	FJ60-121257
	BJ60-000001		FJ60-0950351	538	FJ60-127176
456	BJ60-002678	483	BJ60-0011093		BJ60-014863
457	BJ60-002679		FJ60-0950352	539	FJ60-127177
458	BJ60-004492	486	BJ60-012311		BJ60-014864
	FJ60-023632		FJ60-085310	540	FJ60-120681
459	BJ60-004493	487	BJ60-012312	541	FJ60-120682
	FJ60-023633		FJ60-085311	542	2F-862659
464	BJ60-004492	488	BJ60-0011151	543	2F-862660
	BJ60-023632		FJ60-0063753	544	2F-862582
465	BJ60-004493	489	BJ60-0011152	545	2F-862583
	BJ60-023633		FJ60-0063754	546	2F-860690
466	BJ60-010842	490	FJ60-0072410	547	2F-860691
	FJ60-052956	498	BJ60-0012316 PLANT•A11	554	FJ60-127359
467	BJ60-010843				BJ60-015766
	FJ60-052957		FJ60-0085469 PLANT•A11	555	FJ60-127360
468	2F-636115	499	BJ60-0012317 PLANT•A11		BJ60-015767
469	2F-636116			558	BJ60-014607
470	BJ60-008225		FJ60-0085470 PLANT•A11		FJ60-123574
	FJ60-038414	500	2F-787707	559	BJ60-014608
471	BJ60-008226	501	2F-787708		FJ60-123595
	FJ60-038415	502	BJ60-011863	562	FJ60-127352
472	2F-659319		FJ60-076126	563	FJ60-127353
473	2F-659320	503	BJ60-011864	564	BJ60-015622
474	BJ60-010392		FJ60-076127	565	BJ60-015623
	FJ60-950306	507	FJ60-099857 PLANT•A11	567	HJ60-033418 PLANT• A11
475	BJ60-010393	514	BJ60-014563	574	HJ60-033923
	FJ60-950307	515	BJ60-014864		PLANT• A11
476	3B-502601	534	2F-848881	575	HJ60-033924
477	3B-502602	535	2F-848882		PLANT• A11
480	BJ60-0011525	536	BJ60-014477	576	PLANT• A11
	FJ60-0071392		FJ60-121256	577	PLANT• A11
481	BJ60-0011526	537	BJ60-014478	584	3B-0707773
	FJ60-0071393				

LAND CRJ SER Station Wagon U. S. A.

PRODUCTION FRAME NUMBER REFERENCE LIST

Applicable Model / Production Date / Assembly Line	7001	8002	8003	8004	8005	8006	8007	8008	8009	8010	8011	8012
BJ60	TMC Honsya Plant							000001	000020	000200	000407	000716
FJ60	TMC Honsya Plant							000001	000713	001986	003036	004309

Applicable Model / Production Date / Assembly Line	8101	8102	8103	8104	8105	8106	8107	8108	8109	8110	8111	8112
BJ60	TMC Honsya Plant	001028	001311	001720	002192	002584	002918	003338	003779	004082	004438	005048	005600
FJ60	TMC Honsya Plant	005670	007107	008697	010560	012579	014514	016859	019194	021105	023671	025965	028[illegible]

Applicable Model / Production Date / Assembly Line	8201	8202	8203	8204	8205	8206	8207	8208	8209	8210	8211	8212
BJ60	TMC Honsya Plant	006196	006712	007307	008002	008723	009248	009730	010217	010640	010845	010934	011309
FJ60	TMC Honsya Plant	030472	034596	034980	037650	040275	042527	044579	046330	050095	051992	055398	058504

Applicable Model / Production Date / Assembly Line	8301	8302	8303	8304	8305	8306	8307	8308	8309	8310	8311	8312
BJ60	TMC Honsya Plant	011072	011148	011273	011320	011520	011719	011894	012065	012196	012325	012405	012638
FJ60	TMC Honsya Plant	063[illegible]	063661	066186	066802	071094	[illegible]	076675	079491	082239	085047	[illegible]	[illegible]

Applicable Model / Production Date / Assembly Line	8401	8402	8403	8404	8405	8406	8407	8408	8409	8410	8411	8412
BJ60	TMC Honsya Plant	012757	012976	013089	013321	013545	013798	013991	014217	014406	014652	014866	015046
FJ60	TMC Honsya Plant	0956314	0972754	100915	104147	107146	110866	114414	117871	120722	123958	127349	

Applicable Model / Production Date / Assembly Line	8501	8502	8503	8504	8505	8506	8507	8508	8509	8510	8511	8512
BJ60	TMC Honsya Plant	015271	015437	015624	015767	015942	016130	016498	016701	016809	017141		
FJ60	TMC Honsya Plant			127354	127370	127565	128372	128685	129380	130484	131593	132067	
HJ60	TMC Honsya Plant										000001	333[illegible]	333543

Applicable Model / Production Date / Assembly Line	8601	8602	8603	8604	8605	8606	8607	8608	8609	8610	8611	8612
BJ60	TMC Honsya Plant	133049	133050	133051	133360	134697	134342	134850	135536	135897	136602	137149	137697
HJ60	TMC Honsya Plant	034450	034851	035	035683	036079	036389	036754	037[illegible]	037318	037[illegible]	038032	038420