
180 (1835, 133)
31 (316, 23)
FRONT NO. 1 SPRING BUMPER LH
FRONT LOWER BALL JOINT ATTACHMENT LH
FRONT NO. 2 SUSPENSION TOE ADJUSTING PLATE
NO. 2 CAMBER ADJUSTING CAM
FRONT SUSPENSION TOE ADJUSTING CAM SUB-ASSEMBLY
CAMBER ADJUSTING CAM ASSEMBLY
167 (1703, 123)
280 (2855, 207)
x 2
280 (2855, 207)
300 (3059, 221)
FRONT NO. 1 LOWER ARM BUSH LH
FRONT NO. 2 LOWER ARM BUSH LH
N*m (kgf*cm, ft.*lbf) : Specified torque
FRONT NO. 1 SUSPENSION ARM LOWER SUB-ASSEMBLY LH
Non-reusable part
Do not apply lubricants to the threaded parts
MP grease

P