

# MAINTENANCE

## SCHEDULED MAINTENANCE LOG

### 5,000-Mile Maintenance Intervals 7,500-Mile Maintenance Intervals

To determine the appropriate maintenance interval for your vehicle, see page 85.

#### 5,000 Miles or 4 Months

- ☐ Replace engine oil and oil filter
- ☐ Rotate tires
- ☐ Road test vehicle

#### Additional Maintenance Items for Special Operating Conditions:<sup>1</sup>

- ☐ Inspect the following:
  - \_\_\_\_ Engine air filter
  - \_\_\_\_ Ball joints and dust covers
  - \_\_\_\_ Brake linings/drums and brake pads/discs
  - \_\_\_\_ Drive shaft boots
  - \_\_\_\_ Nuts and bolts on chassis and body
  - \_\_\_\_ Steering linkage and boots

*Dealer Service Verification*  
**LEXUS OF AUSTIN**  
9910 STONELAKE BLVD.  
AUSTIN, TEXAS 78759

Date: 6/21/02  
Mileage: 8549

#### 10,000 Miles or 8 Months

- ☐ Replace engine oil and oil filter
- ☐ Rotate tires
- ☐ Road test vehicle

#### Additional Maintenance Items for Special Operating Conditions:<sup>1</sup>

- ☐ Replace air conditioner filter (RX 300)<sup>2</sup>
- ☐ Inspect the following:
  - \_\_\_\_ Engine air filter
  - \_\_\_\_ Ball joints and dust covers
  - \_\_\_\_ Brake linings/drums and brake pads/discs
  - \_\_\_\_ Drive shaft boots
  - \_\_\_\_ Nuts and bolts on chassis and body
  - \_\_\_\_ Steering linkage and boots

*Dealer Service Verification*

Date: \_\_\_\_\_  
Mileage: \_\_\_\_\_

#### 7,500 Miles or 6 Months

- ☐ Inspect air conditioner filter (LX 470)
- ☐ Replace engine oil and oil filter
- ☐ Rotate tires
- ☐ Road test vehicle

*Dealer Service Verification*

Date: \_\_\_\_\_  
Mileage: \_\_\_\_\_

# SCHEDULED MAINTENANCE LOG

**30,000 Miles or 24 Months**  
**30,000 Miles or 24 Months**

- ☒ Lubricate front drive shaft bushings (LX 470)
- ☒ Lubricate propeller shaft, re-torque bolts (LX 470)
- ☐ Repack front wheel bearings (LX 470)
- ☐ Replace air conditioner filter (LX 470)
- ☒ Replace brake fluid
- ☒ Inspect the following:
  - \_\_\_ Active height control system (LX 470)
  - \_\_\_ Ball joints and dust covers
  - \_\_\_ Body (see page 113)
  - \_\_\_ Brake lines and hoses
  - \_\_\_ Brake linings/drums and brake pads/discs
  - \_\_\_ Drive shaft boots
  - \_\_\_ Exhaust pipes and mountings
- ☒ Replace engine air filter
- ☒ Replace engine coolant
- ☒ Replace engine oil and oil filter
- ☐ Re-torque drive shaft flange bolts (RX 300)
- ☒ Rotate tires
- ☒ Road test vehicle
- \_\_\_ Fuel lines and connections, fuel tank band and fuel tank vapor vent system hoses
- \_\_\_ Fuel tank cap gasket
- \_\_\_ Rack and pinion assembly
- \_\_\_ Steering linkage and boots
- \_\_\_ Transmission, transfer case and differential oil

## Additional Maintenance Items for Special Operating Conditions:<sup>1</sup>

- ☒ Inspect nuts and bolts on chassis and body
- ☐ Replace air conditioner filter (RX 300)<sup>2</sup>
- ☒ Replace differential oil<sup>4</sup>
- ☐ Replace transfer case oil<sup>4</sup>
- ☒ Replace transmission fluid (LX 470)<sup>4</sup>

### Dealer Service Verification

**Park Place Lexus**

9001 State Hwy. 1114 East

Carrollwood, TX 76051

Date: 7/18/03

Mileage: 30341

<sup>1</sup> See page 86 to determine if your vehicle requires these maintenance items.

<sup>2</sup> Only if vehicle is operated primarily on unpaved or dusty roads.

<sup>3</sup> Do not replace if replaced at 20,000 miles/16 months.

<sup>4</sup> Only if vehicle is operated primarily while towing a trailer or using a camper or car-top carrier.



# MAINTENANCE

## SCHEDULED MAINTENANCE LOG

### 5,000-Mile Maintenance Intervals 7,500-Mile Maintenance Intervals

To determine the appropriate maintenance interval for your vehicle, see page 85.

#### 35,000 Miles or 28 Months

- ☐ Replace engine oil and oil filter
- ☐ Rotate tires
- ☐ Road test vehicle

#### Additional Maintenance Items for Special Operating Conditions:<sup>1</sup>

- ☐ Inspect the following:
  - \_\_\_\_ Ball joints and dust covers
  - \_\_\_\_ Brake linings/drums and brake pads/discs
  - \_\_\_\_ Drive shaft boots
  - \_\_\_\_ Engine air filter
  - \_\_\_\_ Nuts and bolts on chassis and body
  - \_\_\_\_ Steering linkage and boots

*Dealer Service Verification*  
**Park Place Lexus Grapevine**  
901 State Hwy. 114 East  
Grapevine, TX 76051

Date: 11/28/03  
Mileage: 35,782

#### 40,000 Miles or 32 Months

- ☐ Replace engine oil and oil filter
- ☐ Rotate tires
- ☐ Road test vehicle

#### Additional Maintenance Items for Special Operating Conditions:<sup>1</sup>

- ☐ Replace air conditioner filter (RX 300)<sup>2</sup>
- ☐ Inspect the following:
  - \_\_\_\_ Ball joints and dust covers
  - \_\_\_\_ Brake linings/drums and brake pads/discs
  - \_\_\_\_ Drive shaft boots
  - \_\_\_\_ Engine air filter
  - \_\_\_\_ Nuts and bolts on chassis and body
  - \_\_\_\_ Steering linkage and boots

*Dealer Service Verification*

Date: \_\_\_\_\_  
Mileage: \_\_\_\_\_

#### 37,500 Miles or 30 Months

- ☐ Inspect air conditioner filter (LX 470)
- ☐ Replace engine oil and oil filter
- ☐ Rotate tires
- ☐ Road test vehicle

*Dealer Service Verification*

Date: 11/28/03  
Mileage: \_\_\_\_\_

# SCHEDULED MAINTENANCE LOG

**45,000 Miles or 36 Months**  
**45,000 Miles or 36 Months**

- ☒ Lubricate propeller shaft, re-torque bolts (LX 470)
- ☒ Replace air conditioner filter<sup>3</sup>
- ☒ Replace engine oil and oil filter
- ☐ Re-torque drive shaft flange bolts (RX 300)
- ☒ Rotate tires
- ☒ Road test vehicle
- ☒ Inspect the following:
  - ☒ Active height control system (LX 470)
  - ☒ Ball joints and dust covers
  - ☒ Body (see page 114)
  - ☒ Brake lines and hoses
  - ☒ Brake linings/drums and brake pads/discs
  - ☒ Differential oil
  - ☒ Drive shaft boots
  - ☒ Exhaust pipes and mountings
  - ☒ Rack and pinion assembly
  - ☒ Steering linkage and boots
  - ☒ Transfer case oil (RX 300)

## Additional Maintenance Items for Special Operating Conditions:<sup>1</sup>

- ☐ Inspect engine air filter
- ☐ Inspect nuts and bolts on chassis and body
- ☐ Replace differential oil<sup>4</sup>
- ☐ Replace transfer case oil (RX 300)<sup>4</sup>

**Park Place Lexus,**  
**901 State Hwy 114E**  
**Grapevine TX 76061**

Date: 1-3-08

Mileage: 48682

<sup>1</sup> See page 86 to determine if your vehicle requires these maintenance items.

<sup>2</sup> Only if vehicle is operated primarily on unpaved or dusty roads.

<sup>3</sup> On RX 300, do not replace if replaced at 40,000 miles/32 months.

<sup>4</sup> Only if vehicle is operated primarily while towing a trailer or using a camper or car-top carrier.



# SCHEDULED MAINTENANCE LOG

**60,000 Miles or 48 Months**  
**60,000 Miles or 48 Months**

- |  |   |
|--|---|
| <input checked="" type="checkbox"/> Lubricate front drive shaft bushings (LX 470)<br><input checked="" type="checkbox"/> Lubricate propeller shaft, re-torque bolts (LX 470)<br><input type="checkbox"/> Repack front wheel bearings (LX 470)<br><input type="checkbox"/> Replace active height control system fluid (LX 470)<br><input checked="" type="checkbox"/> Replace air conditioner filter (LX 470)<br><input checked="" type="checkbox"/> Replace brake fluid<br><input checked="" type="checkbox"/> Inspect the following:<br>Active height control system (LX 470)<br>Ball joints and dust covers<br>Body (see page 115)<br>Brake lines and hoses<br>Brake linings/drums and brake pads/discs<br>Charcoal canister <sup>3</sup><br>Drive belts<br>Drive shaft boots<br>Engine valves (audible) | <input checked="" type="checkbox"/> Replace engine air filter<br><input checked="" type="checkbox"/> Replace engine coolant<br><input checked="" type="checkbox"/> Replace engine oil and oil filter<br><input type="checkbox"/> Replace limited-slip differential oil (RX 300)<br><input type="checkbox"/> Re-torque drive shaft flange bolts (RX 300)<br><input checked="" type="checkbox"/> Rotate tires<br><input checked="" type="checkbox"/> Road test vehicle<br><br><input type="checkbox"/> Exhaust pipes and mountings<br><input type="checkbox"/> Fuel lines and connections, fuel tank band and fuel tank vapor vent system hoses<br><input type="checkbox"/> Fuel tank cap gasket<br><input type="checkbox"/> Rack and pinion assembly<br><input type="checkbox"/> Steering linkage and boots<br><input type="checkbox"/> Transmission, transfer case and differential oil |
|--|---|

## Additional Maintenance Items for Special Operating Conditions:<sup>1</sup>

- |  |   |
|--|---|
| <input type="checkbox"/> Inspect nuts and bolts on chassis and body<br><input type="checkbox"/> Replace air conditioner filter (RX 300) <sup>2</sup> | <input type="checkbox"/> Replace differential oil <sup>4</sup><br><input type="checkbox"/> Replace transfer case oil <sup>4</sup><br><input type="checkbox"/> Replace transmission fluid <sup>4</sup> |
|--|---|

*Dealer Service Verification*  
**001 E State Hwy 114**  
**Grapovine, TX 76051**

Date: 11-14-05  
 Mileage: 60203

<sup>1</sup> See page 86 to determine if your vehicle requires these maintenance items.

<sup>2</sup> Only if vehicle is operated primarily on unpaved or dusty roads.

<sup>3</sup> Inspect at 60,000 miles or 72 months, whichever comes first. Required only for vehicles in California, Massachusetts and New York.

<sup>4</sup> Only if vehicle is operated primarily while towing a trailer or using a camper or car-top carrier.



# MAINTENANCE

## SCHEDULED MAINTENANCE LOG

### 5,000-Mile Maintenance Intervals 7,500-Mile Maintenance Intervals

To determine the appropriate maintenance interval for your vehicle, see page 85.

#### 65,000 Miles or 52 Months

- ☒ Replace engine oil and oil filter
- ☒ Rotate tires
- ☒ Road test vehicle

#### Additional Maintenance Items for Special Operating Conditions:<sup>1</sup>

- ☐ Inspect the following:
  - \_\_\_ Ball joints and dust covers
  - \_\_\_ Brake linings/drums and brake pads/discs
  - \_\_\_ Drive shaft boots
  - \_\_\_ Engine air filter
  - \_\_\_ Nuts and bolts on chassis and body
  - \_\_\_ Steering linkage and boots

**State Place, Texas**  
 Dealer Service Verification  
 State Hwy, 114 East  
 Grapevine, TX 76061

Date: 5-4-04

Mileage: 65,527

#### 70,000 Miles or 56 Months

- ☒ Replace engine oil and oil filter
- ☒ Rotate tires
- ☒ Road test vehicle

#### Additional Maintenance Items for Special Operating Conditions:<sup>1</sup>

- ☐ Replace air conditioner filter (RX 300)<sup>2</sup>
- ☒ Inspect the following:
  - \_\_\_ Ball joints and dust covers
  - \_\_\_ Brake linings/drums and brake pads/discs
  - \_\_\_ Drive shaft boots
  - \_\_\_ Engine air filter
  - \_\_\_ Nuts and bolts on chassis and body
  - \_\_\_ Steering linkage and boots

**State Place, Texas**  
 Dealer Service Verification  
 State Hwy, 114 East  
 Grapevine, TX 76061

Date: 11/21/06

Mileage: 79,165

#### 67,500 Miles or 54 Months

- ☐ Inspect air conditioner filter (LX 470)
- ☐ Replace air conditioner filter (RX 300)<sup>3</sup>
- ☐ Replace engine oil and oil filter
- ☐ Rotate tires
- ☐ Road test vehicle

#### Dealer Service Verification

Date: 11/21/06

Mileage: 79,165

## Maintenance Logs

# SCHEDULED MAINTENANCE LOG

**75,000 Miles or 60 Months**  
**75,000 Miles or 60 Months**

- ☒ Lubricate propeller shaft, re-torque bolts (LX 470)
- ☒ Replace air conditioner filter (LX 470)
- ☒ Replace engine oil and oil filter
- ☐ Re-torque drive shaft flange bolts (RX 300)
- ☒ Rotate tires
- ☒ Road test vehicle
- ☒ Inspect the following:
  - \_\_\_ Active height control system (LX 470)
  - \_\_\_ Ball joints and dust covers
  - \_\_\_ Body (see page 116)
  - \_\_\_ Brake lines and hoses
  - \_\_\_ Brake linings/drums and brake pads/discs
  - \_\_\_ Differential oil
  - \_\_\_ Drive belts
  - \_\_\_ Exhaust pipes and mountings
  - \_\_\_ Rack and pinion assembly
  - \_\_\_ Steering linkage and boots
  - \_\_\_ Transfer case oil (RX 300)

## Additional Maintenance Items for Special Operating Conditions:<sup>1</sup>

- ☒ Inspect engine air filter
- ☐ Inspect nuts and bolts on chassis and body
- ☐ Replace differential oil<sup>4</sup>
- ☐ Replace transfer case oil (RX 300)<sup>4</sup>

**Park Place Lexus**

**901 State Hwy. 114 East**

**Weslaco, TX 76061**

Date: 5/1/07

Mileage: 75288

<sup>1</sup> See page 86 to determine if your vehicle requires these maintenance items.

<sup>2</sup> Only if vehicle is operated primarily on unpaved or dusty roads.

<sup>3</sup> Do not replace if replaced at 60,000 miles/48 months.

<sup>4</sup> Only if vehicle is operated primarily while towing a trailer or using a camper or car-top carrier.



# MAINTENANCE

## SCHEDULED MAINTENANCE LOG

**5,000-Mile Maintenance Intervals**  
**7,500-Mile Maintenance Intervals**

To determine the appropriate maintenance interval for your vehicle, see page 85.

### 80,000 Miles or 64 Months

- ☒ Replace engine oil and oil filter
- ☒ Rotate tires
- ☒ Road test vehicle

#### Additional Maintenance Items for Special Operating Conditions:<sup>1</sup>

- ☐ Replace air conditioner filter (RX 300)<sup>2</sup>
- ☐ Inspect the following:
  - \_\_\_\_ Ball joints and dust covers
  - \_\_\_\_ Brake linings/drums and brake pads/discs
  - \_\_\_\_ Drive shaft boots
  - \_\_\_\_ Engine air filter
  - \_\_\_\_ Nuts and bolts on chassis and body
  - \_\_\_\_ Steering linkage and boots

**Park Place Lexus**

**901 State Hwy 114 East**  
**Grapevine, TX 76051**

Date: 1-2-08

Mileage: 80840

### 85,000 Miles or 68 Months

- ☐ Replace engine oil and oil filter
- ☐ Rotate tires
- ☐ Road test vehicle

#### Additional Maintenance Items for Special Operating Conditions:<sup>1</sup>

- ☐ Inspect the following:
  - \_\_\_\_ Ball joints and dust covers
  - \_\_\_\_ Brake linings/drums and brake pads/discs
  - \_\_\_\_ Drive shaft boots
  - \_\_\_\_ Engine air filter
  - \_\_\_\_ Nuts and bolts on chassis and body
  - \_\_\_\_ Steering linkage and boots

*Dealer Service Verification*

Date: \_\_\_\_\_

Mileage: \_\_\_\_\_

### 82,500 Miles or 66 Months

*Dealer Service Verification*

Date: \_\_\_\_\_

Mileage: \_\_\_\_\_

- ☐ Inspect air conditioner filter (LX 470)
- ☐ Replace engine oil and oil filter
- ☐ Rotate tires
- ☐ Road test vehicle

Maintenance Logs