

Engine Bay


HZJ



LJ




Instrument Panel




無断複製禁止

Body


2-Door HZJ




2-Door LJ



4-Door HZJ





4-Door LJ



無断複製禁止


Relay Block (Under Combination Meter)






Fuse Panel No. 1 (Right Cowl)

①



★ :Medium Current Fuse



無断複製禁止